

Instructions for RCL S transmitter TERL9210XTX (2, 4, 6, 8 Function)

STOP Button: switches off the receiver and the keypad function buttons.

LED: -

Blinks when transmitter and Receiver are active. ON when a transmitter Button is pressed. Pulses if battery is low when transmitting.



The transmitter automatically transmits a **STOP** signal after 30 minutes (default); this de-activates the receiver and the transmitter.

Operating frequency: 418/433 MHz E.R.P < 0.4mW To register transmitters to a 92/93 series receiver

- 1. Coding into Slot 1
 - 1. Turn on receiver, **FAULT** LED will flash.
 - 2. Press and hold SET and F1 on transmitter until FAULT LED remains ON.
 - 3. Release all buttons on transmitter.
 - 4. Check receiver is coded correctly by pressing **SET** then operating any function.
- 2. Coding into Slot 2
 - 1. Turn on receiver, FAULT LED will flash.
 - 2. Press and hold **SET** and **F1** on transmitter one until **FAULT** LED remains ON.
 - 3. Press and hold SET and F1 on transmitter two whilst still holing SET and F1 on transmitter one.
 - 4. Once the **FAULT** LED begins to flash again, release **SET** and **F1** on transmitter one and keep buttons **SET** and **F1** on transmitter two.
 - 5. Continue to hold until **FAULT** LED remains ON.
 - 6. Release all buttons on transmitter.
 - 7. Check receiver is coded correctly by pressing **SET** then operating any function.

DO NOT push any BUTTONS on the handset while replacing the BATTERIES.

If you have any problems please phone TER Tecno Elettrica Ravasi Srl +39 039 99 11 011

F.C.C. PART 15 INTENTIONAL RADIATOR MANUAL STATEMENT RADIO FREQUENCY INTERFERENCE STATEMENT:

This device must accept any interference, including interference that may cause undesired operation of the device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MODIFICATIONS:


Changes or modifications not expressly approved by TER could void the users authority to operate the equipment

IC RADIO STATEMENT:

"Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication."

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: This device may not cause interference. This device must accept any interference, including interference that may cause undesired operation of the device.



SET Button:

activates the

Receiver and

function buttons

Yellow function

Transmitter uses

2 x AAA Alkaline

the keypad

buttons

batteries

Effective working range up to a distance of

60 metres (200 feet) 10 Series