


ATEX SIGNAL LAMPS - STANDARD CODES



Instructions

Fill in the boxes with the numbers/letters corresponding to the specifications required, thus obtaining the stack light code, as shown in the example below.

EX	B	1	F	R	1
-----------	----------	----------	----------	----------	----------